Step-By-Step Quick Start Guide To Using Your Generator

Remove Generator From Package



Oil Type: SAE10W-30 Oil (Must add BEFORE first use) Oil Capacity: 18.5 fluid oz

Because this generator includes Low Oil Shut Off, the generator will not start with low oil. Start out with 18.5 oz, then fill until almost overflowing.)


- dd Fuel If using Gasoline, add Unleaded gasoline only octane rating of 87 or higher. Maximum Capacity: 3.6 Gallon gasoline fuel tank
 - If using Propane, connect Regulator Hose to Propane Tank and the LP Gas Inlet on Generator.
- **Start The Generator**
 - Use the generator OUTDOORS in a WELL VENTILATED AREA.
 - DO NOT CONNECT electrical devices until AFTER the generator is started.
 - Turn Engine Switch to ON A. If using GASOLINE, turn FUEL PETCOCK to ON (Figure A) B. If using PROPANE, turn FUEL PETCOCK to "OFF" (Figure B)
 - Adjust the CHOKE to CLOSED/CHOKE position (Figure C)
 - Start the generator manually with the Recoil (Pull) Start.
 - Once the engine has started, GRADUALLY move the choke lever to the "RUN/OPEN" position until the engine levels off. Then let the engine run approximately 5 minutes BEFORE adding appliances or tools.
 - You can now connect electrical devices.

Fuel Petcock





(Figure B)



LP Gas Inlet





Closed/Choke (Figure C)

GEN4DF

4,000 Surge / 3,500 Running Watts

GENERATOR SPECIFICATIONS:

- 7.0 HP Engine, 4 Stroke OHV
- Recoil Start
- 3.6 Gallon Fuel Tank
- Low Oil Shut Off
- AVR Automatic Voltage Regulation
- UL Listed Electrical Components
- Engine Shut Off Switch
- Circuit Breaker & Power Outlets
- 1 12V D/C Outlet
- 4 120V A/C Outlets
- 1 120V RV Outlet
- Complies with EPA emissions
- DO NOT use E85, gas/oil mix, or modify the engine to run on alternate fuels.
- Run time = 10 hours @ 50% load
- Decibel Rating < 69 db @ 0% load
- Warranty: 2 YEAR limited
- * SURGE WATTS / RUNNING WATTS MAY BE REDUCED BY 10% WHEN USING PROPANE FUEL VS USING GASOLINE.
- If you are using a generator 3,000 ft. above sea level, the generator may not function properly because of air flow getting through the carburetor.
- High Altitude Use: This generator is not recommended for high altitude use 3,000 ft. above sea level.

OIL IS NOT INCLUDED WITH THIS GENERATOR. IT IS SOLD SEPARATELY.

Read and understand instruction manual before using generator.



Add Gasoline

TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436



This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected.

Need Help? Call Customer Service! Monday-Friday 8:00-4:00 Central Time



GEN4DF

CO Warning

4,000 Surge / 3,500 Running Watts

DC Reset AC 120V RV

4000 SURGE WATTS red by GASOLINE OR LPG FUEL **Engine 12V DC 120V AC 120V AC RV AC Reset Switch**

DO NOT CONNECT electrical devices until AFTER the generator is started



IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, **DO NOT OPERATE THIS PRODUCT!**

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far away from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.



This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected.

AWARNING Carbon monoxide (also known as CO) can be dangerous for humans and pets. Carbon monoxide poisoning can lead to death in a very short time. It is called "the silent killer" because it is odorless, tasteless and invisible: you may be exposed without knowing it.

NOTE: The indicator will light RED and the engine will shutdown if dangerous Carbon Monoxide levels are detected. The engine will not restart for 5 minutes. If an error in the carbon monoxide system is detected, the indicator will blink YELLOW and the engine will shutdown for five minutes



AUTOMATIC SHUTOFF - YOU MUST:





MOVE TO FRESH AIR AND GET MEDICAL HELP IF WEAK. MOVE GENERATOR TO AN OPEN, OUTDOOR AREA. POINT EXHAUST AWAY. DON'T RUN GENERATOR IN ENCLOSED AREA (E.G. NOT IN HOUSE OR GARAGE).

READ MANUAL FOR COMPLETE CO WARNING INSTRUCTIONS!

TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436

Need Help? Call Customer Service! Monday-Friday 8:00-4:00 Central Time

