Follow This Step-By-Step **Guide To Using Your Generator**

Remove generator from package

Mix 2-Cycle Oil with Gas

Mix unleaded gasoline with 2-cycle oil for outdoor power equipment with 50:1 mix. (1 gal/2.5 oz)

Add Fuel Remove cap from top of generator and add maximum 1 gallon into fuel tank

Start The Generator

- Use the generator OUTDOORS in a WELL VENTILATED AREA.
- DO NOT CONNECT electrical devices until AFTER the generator is started.
- Turn Power Switch to ON
- Turn FUEL PETCOCK to ON (Figure A)
- Adjust the CHOKE to CLOSED TO START position
- Start the generator manually with the Recoil (Pull) Start.
- Once the engine has started and runs for about a minute, move the choke lever slowly towards the "Open To Run" position.
- You can now connect electrical devices. DO NOT CONNECT electrical devices until AFTER the generator is started.

GENMAX1500

1,500 Surge / 900 Running Watts

GENERATOR SPECIFICATIONS:

- 2 120V A/C Outlet
- 1 12V D/C Outlet
- · Recoil Start
- 2 HP 2-Cycle Fuel Engine
- · Displacement: 72cc
- · Phase: Single
- AC Voltage: 120V @ 60Hz
- Decibel Rating <65 db @ 24 Feet
- Complies with EPA emissions
- Engine Run Time: 8 Hours @ 50% Load
- Fuel Tank Capacity: 1 Gallon
- Fuel: Unleaded Gas & 2-Cycle Oil Mix (50:1)
- DO NOT use E85 or modify the engine to run on alternate fuels.
- High Altitude Use: This generator is not recommended for high altitude use above 3,000 feet above sea level.
- If you are using a generator 3,000 feet above sea level, the generator may not function properly because of air flow getting through the carburetor

2-CYCLE OIL IS NOT INCLUDED WITH THIS **GENERATOR. IT IS SOLD SEPARATELY.**

Read and understand instruction manual before using generator.

Fuel Petcock





(Figure A)



IF THERE IS ANY QUESTION ABOUT CONDITION BEING SAFE OR UNSAF DO NOT OPERATE THIS PRODUCT!

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far way from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.



TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436



This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected.


Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time



GENMAX1500

1,500 Surge / 900 Running Watts

CONTROL PANEL FEATURES




DO NOT CONNECT electrical devices until AFTER the generator is started.

NOTES

Outlets available on this generator, from left to right:

- 2 x 120 Volt A/C Outlet
- 1 x 12 Volt D/C Outlet



WARNING

IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far way from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.

TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436

Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time

